

CHARCOAL FIRED PORTA-GRILL®

Section A - Grill Assembly

- 1) Turn firebox onto one side and screw each of (4) leg and caster assemblies into threaded couplers.
- 2) Attach grill supports to firebox using (4) 3/8" - 16 x 1" bolts and nuts provided. Note: Grill support bolts go through the firebox and then the grill support with the grill support on the inside of the firebox. Hood pin should face outward.
- 3) Install nickel chrome plated cooking grate.

Section B – Optional PG-360 Hood Assembly

- 1) Place inner hood half over rear of grill with handles to the rear, (grill grate supporting hooks face the front of the grill). Lift ends of hood over 1/2" pivot pins one side at a time.
- 2) Place outer hood half over inner hood half with handles to the front of the grill. Lift ends of hood over 1/2" pivot pins one side at a time.
- 3) With front of the hood in half open position, install the thermometer, using the retaining clip provided to hold the thermometer in placed.
- 4) Retaining hair pins should be attached to hood pivot pins.

Section A – Grill Assembly

